

=====

INSTALLATION INSTRUCTIONS FOR RSPFILE*

=====

Do not unzip or extract the license file

- Save the P821910xxxx-X, K18488xxxx-X, K80588xxxx-X, M20788xxxx-X or V20896xxxx-X .ZIP.RSP license file to an easy to browse to location (suggest c:\) on the PLOTBASE | 3 Computer
- Start your PLOTBASE application
- Choose "License Manager" from the "HELP" menu of PLOTBASE
- Inside the License Manager application, Click on the "Update Licenses" button
- Browse to the location that you saved the attached license file to (c:\) and select it [do not unzip or extract the file]
- Click on the "Install" button. You may check within the license properties (scroll through the newly applied license to see if your options (Scan, PDF, etc.) are listed
- When you see the response "License has already been installed, click 'OK', then exit the License Manager application
- Restart the PLOTBASE application, and the features in the license will then become available

Contact RATIO if you need the latest update version of PLOTBASE Software for Windows 7, PS/PDF versions or CAD application drivers

Controller cards, Scan, PDF, DWG options, cables & PLOTBASE support available for all Ricoh Wide Format Copiers

Re-certified Dell PCs available - Single Core which is required for earlier generation RW-470 / RW-240 /RW-480 controller cards.

High performance RIP CUBE PCs for PLOTBASE pre-installed, plug & play solutions: http://www.ratio.us/rip_cube/

email: support@ratio.us

web: <http://www.ratio.us> <http://www.plotbasepm.com>

Phone: U.S. 262-558-4900